



# BETASEAL™ 58702SFLN

## Glass Bonding Systems

BETASEAL™ 58702SFLN is one component, moisture curing adhesive with excellent sag and bead stability based on polyurethane chemistry. The adhesive cures with environmental moisture and skin formation and curing is dependent on humidity, temperature and application dimensions.

BETASEAL™ 58702SFLN is cold processable, standard viscosity, lower modulus, glass bonding adhesive.

### Product information

Colour	Black
Basis	Polyurethane
Solid content	≥99 %

### Uncured properties

Skinning time	30 - 50 min
Sagging	0

### Rheological properties

Cup Viscosity	20 - 50 <sup>[1]</sup> s
---------------	--------------------------

[1]: 20g sample; 4mm/.157in orifice at 23°C/73°F and 550 kPa/80 psi

### Application technique

Processing temperature	64.4 - 95 °F
------------------------	--------------

### Cured properties

Temperature stability	-40 - 212 °F
-----------------------	--------------

### Typical mechanical properties

Tensile Modulus	290.076 psi	ISO 527-1/-2
Tensile Strength	1160 psi	ASTM D 412
Elongation at break	550 %	ASTM D 412
Shear modulus	≥145 <sup>[2]</sup> psi	
Lap shear strength, 3 days	≥493 psi	DIN EN 1465
Shore A hardness	45	ASTM D 2240

[2]: 10% Strain

### Other properties

Density	9.85 lb/gal	ISO 1183
---------	-------------	----------



# BETASEAL™ 58702SFLN

## Glass Bonding Systems

### Storage and stability

Shelf life

6<sup>[3]</sup> months

[3]: Short time storage temperatures: 0°C/32°F to 40°C/104°F. From date of manufacture at +5°C/41°F to +35°C/95°F in unopened containers.

### Additional information

How to use

#### Resistance to Chemicals:

BETASEAL™ 58702SFLN is highly resistant to aqueous chemicals, petrol, alcohol and mineral oils; conditionally to esters, ketones, aromatics and chlorinated hydrocarbons.

#### Bonding Surface Preparation:

For BETASEAL™ 58702SFLN all bonding surfaces must be free of dirt, dust, water, oil and grease. Verify compatibility or consult our technical service department.

#### Cleaning:

Uncured adhesive residues of BETASEAL™ 58702SFLN can easily be removed with Isopropanol or similar solvent. (Test non visible area of substrate with solvent to confirm it won't affect the topcoat). Hardened adhesive residues can only be removed mechanically.

#### Information:

Dupont Automotive products are primarily developed in co-operation with the automobile manufacturers, according to their needs and their specifications, they are approved for the specific applications as defined by the customer. The use of the product other than approved application have to be released in written form by a DuPont Technical Service representative.

## DuPont

The information set forth herein is furnished free of charge, is based on technical data that DuPont believes to be reliable, and represents typical values that fall within the normal range of properties. This information relates only to the specific material designated and may not be valid for such material used in combination with other materials or in other processes. It is intended for use by persons having technical skill, at their own discretion and risk. This information should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards and comply with applicable law. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract or other acknowledgement that is consistent with the DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative.

DuPont's sole warranty is that our products will meet our standard sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DUPONT SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR NON-INFRINGEMENT. DUPONT DISCLAIMS LIABILITY FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.